PLMP3C31B

Wireless FM Transmitter for

CD / MP3 / iPod / USB / SD Card Input

Instruction Manual



KEY FEATURES:

- LCD Display Screen
- Wireless Cell Phone Mobile Interface
- Wireless FM Transmitter
- USB/SD Card Compatible
- USB 5V~900Mha Charging Port
- 3.5 Aux Input Adaptor for IPOD, normal Mp3/4....
- Fully Adjustable Arm for Multi Angle Viewing
- Wireless Full Function Remote Control
- Cigarette Lighter DC 12 Volt Compatible

USING THE USB CHARGER:

Use the USB cable that comes with your hand-held portable devices, Plug the USB cable into the USB port, and plug the other end into your portable device. The 5v USB output can be used with normal MP3 players, mobile phones, PDA's and other hand-held devices.

Output power: 5V~900MHA

USING THE FM TRANSMITTER:

Insert this FM transmitter into your vehicle's cigarette lighter or power port

Tune to your radio to a desired FM frequency, then match that same frequency on to the player by using the buttons on the unit or on the remote control.

Plug USB disk or SD card into this product, It will play and transmit the Mp3 files automatic. (You have to copy the MP3 files into the USB disk or SD card in advance.)

This product supports other devices: normal mp3/4, CD... Using the 2.5mm to 3.5mm audio cable provided. Plug one jack into this transmitter, The other end into normal Mp3/4, CD...It will play and transmit the songs from the MP3/4.CD. When connected via input cable, all functions will now need to be controlled on the device, not this transmitter or it's Remote Control. Enjoy!

USING THE BLUETOOTH HANDSFREE:

- 1. Insert this FM transmitter into your vehicle's cigarette lighter or power port.
- 2. Tune your radio to a desired FM frequency, then match the frequency on the player up to your radio by using the buttons on the unit or on the remote control.
- 3. Bluetooth matching:

For the first time using handsfree function, you need match your mobile phone with the device: activate your mobile phone's bluetooth function on, then search new device, while the mobile searched the CAR KIT, please pair and connect it by using the original password "0000". The Bluetooth logo on the screen will stop leaping after connected with mobile phone.

- 4. In the music play / pause mode, if there are calls, the machine will automatically switch to call state.
- 5. Bluetooth calling:
 - 1). To answer calls: Press ▶/॥ button

Or press 3 key on remote controller

2). To hang up calls: Press ▶/॥ button

Or Press 6 key on remote controller

3). If making a call, please use your mobile phone to dial the number. Once the connection is established, you can talk to this player directly.

How to adjust the screen brightness:

Long press "CH" button for about 4 seconds.

Short press "▶" button continuously to turn up the screen brightness;

Short press "◄" button continuously to turn down the screen brightness.

QUICK GUIDE:

Operation Guide	FM transmitter	Remote Controller
1.How to play and stop the music	Press "PLAY" Button : Play the music Second Press "PLAY" Button: Stop	Press PLAY/PAUSE Button
2.How to adjust the Volume	Long Press "▶" button :Increase the Volume ; Long press "◄" Button :Decrease the Volume	Press "VOL+"" Increase the Volume ; Press "VOL-"" reduce the Volume ;
3.How to change the frequency	Press "CH" button first, then press "▶": increase the frequency Press "◄": decrease the frequency	Press "CH+" button: Increase 0.1MHZ Press "CH-" button: reduce 0.1MHZ Or press the number of the frequency what you desired,press"CH+"again to confirm
4.How to choose music	Short Press "▶"Button: Play the next song; Short Press "◄" Button: Play the previous song;	Press "NEXT"Button: Play the next song; Press "PREV" Button: Play the previous song; Or press the serial number of the song directly
5.How to set EQ	Nonsupport	Press "EQ" button to switch your favorite EQ
6.How to change loop mode	Long press "play/pause" button, four loop modes optional: folder, single, random, all	Long press "play/pause" button
7.How to answer/hang up the calls	Press "play/pause" button	Press" \(^"button\)